

VERSASPA[®]

SUNLESS SKIN CARE SYSTEM

Maintenance Checklist

For week of: ____ / ____ / ____

	SUN	MON	TUES	WED	THURS	FRI	SAT
<i>Please initial when each step is complete</i>							
Daily: After Last Session of the Day							
Thoroughly wipe down and clean the inside of the booth							
Check solution levels and replace when level no longer visible in preview window on box							
Turn the water off to the booth							
Weekly:							
Clean every surface of the VersaSpa with warm water and a soft towel (a small amount of mild soap may be used)							
Remove and rinse the 1st stage exhaust filter							
Remove and rinse the sump pump filter							
Monthly:							
Wipe down and clean the sump pump basin							
Remove and rinse the 2nd stage exhaust filter							
Clean solution connectors and drawer tray							
Clean the upper and lower turbine intake filters							
Remove and rinse the air caps							

**** Maintenance may need to be increased due to high session volume ****

Sunless, Inc. Technical Support:
 1.855.450.3500
www.sunlessinc.com/techsupport